

TS[®] 44DLX

for Hearing-Impaired Users

Special Operating Instructions

Safety Information

Caution

People without a hearing impairment could damage their hearing if they use this test set. The test set is labeled CAUTION-HOT RECEIVER to warn you of this. Alert all technicians working around this test set that it is designed for hearing-impaired users.

Operation

To activate the receiver in Monitor mode, press the VOL button. There is no passive-Monitor mode on this test set.

To adjust the volume, use a small screwdriver to turn the volume adjustment screw on the side of the test set.

PN 2448528

October 2005

©2005 Fluke Corporation. All rights reserved. Printed in China.
All product names are trademarks of their respective companies.

Note

The volume control affects only the level of the received signal. It does not affect the level of the transmitted signal.

Contacting Fluke Networks



www.flukenetworks.com



support@flukenetworks.com



1-425-446-4519 or 1-800-283-5853

Visit the Fluke Networks website for a complete list of phone numbers.